



# MAX3678 Evaluation Kit

## General Description

The MAX3678 evaluation kit (EV kit) is a fully assembled and tested demonstration board that simplifies evaluation of the MAX3678 low-jitter frequency synthesizer with intelligent dynamic switching (IDS). The EV kit includes slide switches to allow easy selection of different modes of operation. Clock I/Os have SMA connectors and are AC-coupled to simplify connection to test equipment. The EV kit is powered by a +3.3V supply and uses LEDs for signal status indicators.

## Features

- ◆ Fully Assembled and Tested
- ◆ Slide Switches for Mode Control
- ◆ SMA Connectors and AC-Coupled Clock I/Os
- ◆ Powered by +3.3V Supply
- ◆ LED Signal Status Indicators

## Ordering Information

| PART          | TYPE   |
|---------------|--------|
| MAX3678EVKIT+ | EV Kit |

+Denotes lead-free/RoHS compliant.

## Component List

| DESIGNATION  | QTY | DESCRIPTION   |
|--|-----|---|
| C1, C6, C7<br>C11–C13, C16,<br>C18–C22,<br>C24–C27, C29,<br>C30, C32–C39,<br>C41, C42,<br>C46–C50,<br>C62, C63 | 35  | 0.1 $\mu$ F $\pm$ 10% ceramic capacitors (0402)                   |
| C2   | 1   | 33 $\mu$ F $\pm$ 5% tantalum capacitor (B case)                   |
| C3   | 1   | 2.2 $\mu$ F $\pm$ 10% ceramic capacitor (0805)                    |
| C4   | 1   | 0.1 $\mu$ F $\pm$ 10% ceramic capacitor (0603)                    |
| C5   | 1   | 0.01 $\mu$ F $\pm$ 10% ceramic capacitor (0603)                   |
| C28  | 1   | 0.22 $\mu$ F $\pm$ 10% ceramic capacitor (0402)                   |
| D1, D3, D5,<br>D6, D8  | 5   | Green SMD LEDs (1206)<br>Panasonic LNJ311G8PRA                    |
| D2, D4, D7   | 3   | Red SMD LEDs (1206)<br>Panasonic LNJ211R8ARA                      |
| J1, J2,<br>J5–J12, J14,<br>J15, J19, J20,<br>J22–J29,<br>J44, J45  | 24  | SMA connectors, edge-mount,<br>tab center<br>Johnson 142-0701-851 |
| J4, J13  | 2   | Test points<br>Keystone 5000                                      |
| L13  | 1   | 4.7 $\mu$ H $\pm$ 20% inductor<br>Taiyo Yuden CBC3225T4R7M        |

| DESIGNATION                         | QTY | DESCRIPTION   |
|-------------------------------------|-----|---|
| R1–R5, R15,<br>R16, R17,<br>R37–R46 | 18  | 143 $\Omega$ $\pm$ 1% resistors (0402)  |
| R6–R11                              | 6   | 49.9 $\Omega$ $\pm$ 1% resistors (0402)   |
| R12, R13, R14,<br>R18–R22           | 8   | 332 $\Omega$ $\pm$ 1% resistors (0603)  |
| R23, R24, R25                       | 3   | 10k $\Omega$ $\pm$ 1% resistors (0603)  |
| S1                                  | 1   | Switch, momentary, SPST-NO<br>Panasonic EVQQ2S02W   |
| S2–S5                               | 4   | Switches, slide, SPDT<br>Copal Electronics CUS-12TB   |
| S6, S7, S8                          | 3   | Switches, slide, SP4T<br>Copal Electronics CUS-14TB   |
| S9, S10                             | 2   | Switches, slide, SP3T<br>Copal Electronics CUS-13TB   |
| TP1, TP3, TP20                      | 3   | Test points<br>Keystone 5000  |
| U1–U4                               | 4   | Dual inverters (6 SC-70)<br>TI SN74LVC2G14DCKR  |
| U7                                  | 1   | Low-jitter, frequency synthesizer<br>with intelligent dynamic switching<br>(56 TQFN)<br>Microsemi MAX3678UTN+ |
| None                                | 1   | PCB: MAX3678 EV Kit+ Circuit<br>Board, Rev A  |

Evaluates: MAX3678

# MAX3678 Evaluation Kit

## Quick Start

- 1) Set the slide switches to the following settings:  
 PLL\_BYPASS = NORMAL  
 SEL\_CLK = REFCLK0  
 IDS\_MODE = AUTO  
 DM = 133.33M  
 DA = 133.33M  
 DB = 133.33M  
 $\overline{\text{OUTA\_EN}}$  = A0, A1  
 $\overline{\text{OUTB\_EN}}$  = B0  
 FB\_SEL = INTERNAL
- 2) Connect a +3.3V supply to VCC (J13) and GND (J4). Set the supply current limit to 450mA.
- 3) Using SMA cables, connect a low-jitter 133.33MHz differential clock source to the REFCLK0 input. Verify that the green LEDs switch on for CLK\_SELECTED (REFCLK0),  $\overline{\text{IN0FAIL}}$ , and  $\overline{\text{LOCK}}$ .
- 4) Using SMA cables, connect the OUTA0 output to test equipment. Terminate all unused enabled outputs (OUTB0 and OUTA1).

## Detailed Description

The MAX3678 EV kit simplifies evaluation by providing the hardware needed to evaluate all the MAX3678 functions. Table 1 contains functional descriptions for the switches and indicators.

### Clock Inputs

The clock inputs (REFCLK0, REFCLK1, FB\_IN) are AC-coupled at the SMA connectors and have on-board 100 $\Omega$  differential terminations. For optimal jitter performance it is critical to use a low-jitter, differential, square-wave clock source. If such a source is not available, the clock inputs can be driven with a single-ended sinusoidal or square-wave clock source for functional testing.

### Clock Outputs

The clock outputs (OUTA[3:0], OUTB[4:0]) have on-board DC-biasing and are AC-coupled at the SMA connectors to allow direct connection to 50 $\Omega$ -terminated test equipment. Unused outputs should be disabled (using switches S9 and S10) or have 50 $\Omega$  terminations placed on the SMA connectors.

**Table 1. Switch and Indicator Descriptions**

| COMPONENT | NAME                         | FUNCTION  |
|-----------|------------------------------|---|
| S1        | MASTER RESET                 | Momentary switch to reset internal dividers. Not required at power-up. If the output divider settings (DA, DB) are changed on the fly, a reset is required to phase align the outputs.        |
| S2        | PLL_BYPASS                   | Selects normal PLL operation or PLL bypass.   |
| S3        | SEL_CLK                      | Selects the reference clock input (see IDS_MODE).   |
| S4        | IDS_MODE                     | Selects IDS mode of operation. Auto mode allows IDS to automatically select the reference clock input. Manual mode forces IDS to select the reference clock input selected by SEL_CLK.        |
| S5        | FB_SEL                       | Selects internal or external feedback for the PLL. If external is selected, connect any of the A-group or B-group outputs to the FB_IN input. If DA $\neq$ DB, a B-group output must be used. |
| S6        | DM                           | Selects the frequency of the reference clock inputs.  |
| S7        | DA                           | Selects the frequency of the A-group clock outputs.   |
| S8        | DB                           | Selects the frequency of the B-group clock outputs.   |
| S9        | $\overline{\text{OUTA\_EN}}$ | Selects which A-group outputs are enabled (see note).   |
| S10       | $\overline{\text{OUTB\_EN}}$ | Selects which B-group outputs are enabled (see note).   |
| D1, D2    | $\overline{\text{IN0FAIL}}$  | REFCLK0 failure indicator (green = pass, red = fail).   |
| D3, D4    | $\overline{\text{IN1FAIL}}$  | REFCLK1 failure indicator (green = pass, red = fail).   |
| D5, D6    | CLK_SELECTED                 | Indicates which reference clock input is being used by the PLL.   |
| D7, D8    | $\overline{\text{LOCK}}$     | PLL lock indicator (green = PLL locked, red = PLL not locked).  |
| TP1       | $\overline{\text{BUSY}}$     | Test point for $\overline{\text{BUSY}}$ indicator. Low indicates IDS is busy switching reference clocks.  |

**Note:** Setting  $\overline{\text{OUTA\_EN}}$  = “—” and  $\overline{\text{OUTB\_EN}}$  = “B0” at the same time enables a factory test mode and is not a valid mode of operation.

# MAX3678 Evaluation Kit

Evaluates: MAX3678




Figure 1. MAX3678 EV Kit Schematic

# MAX3678 Evaluation Kit

Evaluates: MAX3678




Figure 2. MAX3678 EV Kit Component Placement Guide—Component Side

# MAX3678 Evaluation Kit

Evaluates: MAX3678




Figure 3. MAX3678 EV Kit PCB Layout—Component Side

# MAX3678 Evaluation Kit

**Evaluates: MAX3678**




Figure 4. MAX3678 EV Kit PCB Layout—Ground Plane

# MAX3678 Evaluation Kit

Evaluates: **MAX3678**




Figure 5. MAX3678 EV Kit PCB Layout—Power Plane

# MAX3678 Evaluation Kit

Evaluates: MAX3678




Figure 6. MAX3678 EV Kit PCB Layout—Solder Side



# MAX3678 Evaluation Kit

Evaluates: MAX3678




Figure 7. MAX3678 EV Kit Component Placement Guide—Solder Side



**Microsemi Corporate Headquarters**  
One Enterprise, Aliso Viejo CA 92656 USA  
Within the USA: +1 (949) 380-6100  
Sales: +1 (949) 380-6136  
Fax: +1 (949) 215-4996

Microsemi Corporation (NASDAQ: MSCC) offers a comprehensive portfolio of semiconductor solutions for: aerospace, defense and security; enterprise and communications; and industrial and alternative energy markets. Products include high-performance, high-reliability analog and RF devices, mixed signal and RF integrated circuits, customizable SoCs, FPGAs, and complete subsystems. Microsemi is headquartered in Aliso Viejo, Calif. Learn more at [www.microsemi.com](http://www.microsemi.com).

---

© 2012 Microsemi Corporation. All rights reserved. Microsemi and the Microsemi logo are trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.